

Corob Cutter™ MOLDING KNIFE PROFILE CHART

These Molding Knives can be used on a table saw or radial arm saw with the MHK-25 Cutter Head. See below for ordering instructions.

| | | | |
|---|--|---|---|
|  1 TONGUE |  2 GROOVE |  3 BEAD & QTR. RND. |  4 1/4" & 1/2" QTR. RND. |
|  5 5/16" COVE & 3/8" BEAD |  6 3 BEAD (3/16") |  7 JOINTER |  8 DROP LEAF BEAD |
|  9 DROP LEAF COVE |  10 BEAD |  11 CROWN |  12 3 BEAD EDGE |
|  13 GLUE JOINT |  14 CLOVER LEAF |  15 3/16" COVE & BEAD |  16 3/16" BEAD & COVE |
|  17 3 BEAD & BEVEL |  18 CABINET DOOR LIP |  19 BEAD & BEVEL |  20 QTR. RND & COVE |
|  21 OGEE |  22 3 FLUTE (1/4") |  23 3 BEAD (1/4") |  24 90° FLUTE |
|  25 CURVED FLUTE & QTR. RND. |  26 5/16" COVE & QTR. RND. |  27 3/4" FLUTE |  28 3/4" NOSING |
|  29 PANEL CUPBOARD DOOR |  30 PANEL DOOR - RAIL COPER |  31 TAPER EDGE |  32 1/8" RADIUS EASED EDGE |
|  33 1/2" RADIUS BASE SHOE |  34 1/2" FLUTE |  35 1/2" NOSING |  36 1" FLUTE |
|  37 DRAWER JOINT |  38 1/8" & 1/4" EASED EDGE |  39 1-5/8" PANEL MOLDING | |
|  40 WEDGE TONGUE |  41 WEDGE GROOVE |  42 DOOR MOLDING (MALE) |  43 DOOR MOLDING (FEMALE) |
|  44 5/8" COVE |  45 THUMB MOLDING |  46 TABLE EDGE |  47 5/8" FLUTE |
|  48 5/8" BEAD | | | |



To place an order - visit us online at
www.corobcutters.com or
 call us Toll Free 1-800-745-9895