

SHAPER CUTTER PROFILE CHART

These Shaper Cutters can be used directly on a shper, radial arm saw, 1/2" capacity routers or with the addition of our ADP10 - high speed drill presses.
See below for ordering instructions.

 1 TONGUE	 2 GROOVE	 3 BEAD & QTR. RND.	 4 1/4" & 1/2" QTR. RND.	 5 5/16" COVE & 3/8" BEAD	 6 3 BEAD (3/16")
 7 JOINTER	 8 DROP LEAF BEAD	 9 DROP LEAF COVE	 10 BEAD	 11 CROWN	 12 3 BEAD EDGE
 13 GLUE JOINT	 14 CLOVER LEAF	 15 3/16" COVE & BEAD	 16 3/16" BEAD & COVE	 17 3 BEAD & BEVEL	 18 CABINET DOOR LIP
 19 BEAD & BEVEL	 20 QTR. RND & COVE	 21 OGEE	 22 3 FLUTE (1/4")	 23 3 BEAD (1/4")	 24 90° FLUTE
 25 CURVED FLUTE & QTR. RND.	 26 5/16" COVE & QTR. RND.	 27 3/4" FLUTE	 28 3/4" NOSING	 29 PANEL CUPBOARD DOOR	 30 PANEL DOOR - RAIL COPER
 31 TAPER EDGE	 32 1/8" RADIUS EASED EDGE	 33 1/2" RADIUS BASE SHOE	 34 1/2" FLUTE	 35 1/2" NOSING	 36 1" FLUTE
 37 DRAWER JOINT	 38 1/8" & 1/4" EASED EDGE	 39 1-5/8" PANEL MOLDING		 40 WEDGE TONGUE	 41 WEDGE GROOVE
 49 1/4" FLUTE	 50 1/4" BEAD	 51 3/8" FLUTE	 52 3/8" BEAD	 53 1/4" GROOVE	 54 5 BEAD (1/8")
 55 9/16" QTR. RND.	 56 OGEE & BEAD TABLE EDGE	 57 1/2" & 1/4" RADII R.H.	 58 1/2" GROOVE	 59 1" CONVEX EDGE	 60 1" BEAD
 61 FEMALE SWASH	 62 MALE SWASH	 63 1-1/2" JOINTER			

Corob Cutter™

To place an order - visit us online at www.corobcutters.com or call us Toll Free 1-800-745-9895.